

# RPW Bias Current Setting Operation Validation

Description of the validation of the Bias Current Setting Operation Implementation.

---

## General

### Purpose & Objectives

The Bias intensity current values applied in the three RPW antennas on-board will be set by commands every week (see ROC-OPS-OTH-ICD-00022-LES for more details).

The full life-cycle must be validated in-flight to ensure the ROC and Bias teams are operational to perform this activity.